


PD-130VR

(GB) OWNER'S OPERATING MANUAL



69800975-00 STD

KYOCERA Industrial Tools Corporation 2-2-54 Matsuhama-cho, Fukuyama-shi, Hiroshima-ken, 720-0802 Japan

─ GB ENGLISH •

DRILLING IN METALMetals such as steel brass, aluminum sheets, stainless steel, and pipe may also be drilled. Mark the point to be drilled with a nail or a punch.

DRILLING IN CONCRETE

Rock and masonry are generally drilled in the impact

Rock and masonry are generally drilled in the impact mode.

When drilling delicate materials such as wall tiles, it is essential to start with ordinary drilling and once the tile is pierced, to continue with impact drilling.

In deep boreholes the drill bit should be pulled out occasionally in order to remove the dust and chips from the hole.

AUX. HANDLE AND ADJUSTMENT STOPPER

Install the aux. handle (7) on the head of the housing and insert the adjustment stopper (6) in the hole provided. The aux. handle can swivel 360° for the most comfortable position and easiest operation. The stopper helps keep an accurate depth when drilling holes.

MAINTENANCE

After use, check the tool to make sure that it is in top condition. It is recommended that you take this tool to an Authorised Service Centre for a thorough cleaning and lubrication at least once a year.

DO NOT MAKE ANY ADJUSTMENTS WHILE THE MOTOR

ALWAYS DISCONNECT THE POWER CORD FROM THE RECEPTACLE BEFORE CHANGING REMOVABLE OR EXPENDABLE PARTS (BLADE, BIT, SANDING PAPER ETC.), LUBRICATING OR WORKING ON THE UNIT.

To ensure safety and reliability, all repairs should be performed by an AUTHORISED SERVICE CENTRE or other QUALIFIED SERVICE ORGANISATION.


SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.





" WARNING To reduce the risk of injury, user must read instruction married." instruction manual





Class II construction tool in which protection against electric shock does not rely on basic insulation only, but in which additional safety precaution, such as double insulation or reinforced insulation, are provided."













THANK YOU FOR BUYING OUR PRODUCT.

To ensure your safety and satisfaction, carefully read through this OWNER'S MANUAL before using the product.

General power tool safety warnings

⚠WARNING Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mainsoperated (corded) power tool or battery-operated (cordless)

1) Work area safety

- a) Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.

 c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose

2) Electrical safety

- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapt-er plugs with earthed (grounded) power tools. Un-modified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if
- your body is earthed or grounded.

 Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the
- d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric
- f) If operating a power tool in a damp location unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock

3) Personal safety

- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- b) Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- personal injuries.

 Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

- d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
 f) Dress properly. Do not wear loose clothing or jew-
- ellery. Keep your hair and clothing away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.
 h) Do not let familiarity gained from frequent use of
- tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.

4) Power tool use and care

- a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
 c) Disconnect the plug from the power source and/
- or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power
- tools are dangerous in the hands of untrained users.
 e) Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- h) Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

5) Service

a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is main-

IMPACT DRILL SAFETY WARNINGS

- 1. Wear ear protectors when impact drilling. Exposure to noise can cause hearing loss
- 2. Use the auxiliary handle(s). Loss of control can cause
- personal injury.

 3. Brace the tool properly before use. This tool produces a high output torque and without properly bracing the tool during operation, loss of control may occur resulting in personal injury

— GB ENGLISH —

- 4. Hold the power tool by insulated gripping surfaces, when performing an operation where the cutting accessory may contact hidden wiring or its own cord. Cutting accessory contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.
- Never operate at higher speed than the maximum speed rating of the drill bit. At higher speeds, the bit
- is likely to bend if allowed to rotate freely without contacting the workpiece, resulting in personal injury.

 6. Always start drilling at low speed and with the bit tip in contact with the workpiese. At higher speeds, the bit is likely to bend if allowed to rotate freely without
- contacting the workpiece, resulting in personal injury.

 Apply pressure only in direct line with the bit and do not apply excessive pressure. Bits can bend causing breakage or loss of control, resulting in per-
- sonal injury.

 8. Make sure drill bit is securely mounted. An incorrectly mounted bit is extremely dangerous since it can fly off
- or break during drilling.

 9. Do not wear cloth gloves or a necktie since they could become caught in a rotating bit. Never touch the chuck or metal body parts when drilling walls, floors, or other surfaces covering electrical
- wiring. Hold the drill only by the plastic handle to prevent electric shock.

 11. While operating the workpiece must be held with the
- vise or the clamp etc. securely, for preventing to move it by the drill rotation.

INSTRUCTIONS FOR SAFE HANDLING

- Make sure that the tool is only connected to the voltage marked on the name plate.
- 2. Never use the tool if its cover or any bolts are missing. If the cover or bolts have been removed, replace them prior to use. Maintain all parts in good working order.
- Always secure tools when working in elevated posi-
- 4. Never touch the blade, drill bit, grinding wheel or other moving parts during use. 5. Never start a tool when its rotating component is in
- contact with the workpiece.

 6. Never lay a tool down before its moving parts have
- come to a complete stop.
- come to a complete stop.
 ACCESSORIES: The use of accessories or attachments other than those recommended in these instructions might present a hazard.
 REPLACEMENT PARTS: When servicing use only

DESCRIPTION

- 1. Drill chuck Switch
- Lock button
- Reversing lever
- Impact shifting knob Adjustment stopper
- Aux. handle Chuck key
- Drill bit
- 10. Speed control dial

SPECIFICATIONS

Chuck capacity Drilling capacity in wood 13 mm (1/2") 25 mm (1") 13 mm (1/2") in steel 13 mm (1/2") 650 W Input 0 - 2,800 min⁻¹ 0 - 28,000 min⁻¹ No load speed Blows per minute 299 mm (11-3/4") 1.75 kg (3.9 lbs.) Overall length Net weight

STANDARD ACCESSORIES

Aux. handle, Adjustment stopper, Chuck key

APPLICATIONS

(Use only for the purposes listed below.)

Drilling wood, metal and resin boards.
 Drilling concrete (impact drill only).

MOUNTING OF BIT (Fig. 1)

When mounting the drill bit (9), insert the bit into chuck (1) as far as it will go and tighten securely using the chuck key (8) provided. There are three holes into which the chuck key should be inserted. Tighten each one equally in turn.

The bit can be removed by following the above method in

SWITCH (Fig. 2)

This tool starts and stops by depressing and releasing the switch(2).

can be adjusted from 0 through regulating the trigger-squeezing force. For continuous operation, press the lock button(3) while switch is depressed. Depress again to release the lock.

The speed control dial(10) allows setting a limit on the de-

CHANGING DIRECTION (Fig. 2)

To reverse the direction of rotation, stop the drill by releasing the trigger and push the reversing lever (4) to the right or left.

When the reversing switch is in the position marked "F", the direction of rotation will be clockwise when viewed from the handle end of the drill. When the reversing switch is in the position marked "R", the direction of rotation will be counter-

CHANGING DRILLING MODE (Fig. 3)

An impact shifting knob (5) has been provided on top of the

- Shift the impact knob to the symbol indicating " " for rotation without impact action. DRILLING IMPACT MODE -Shift the impact knob to the symbol indicating for impact drilling.

OPERATING (Fig. 4)
NEVER COVER AIR VENTS SINCE THEY MUST ALWAYS
BE OPEN FOR PROPER MOTOR COOLING.

DRILLING IN WOOD

To prevent ugly splits around the drillhole on the reverse side of the workpiece, place a scrap piece of lumber beneath the material to be drilled.